

## Product information according to Commission regulation (EU) No 66/2014

Attribute Name	Position	Symbol	Value	Unit
Model Denomination			EIV84550 949599217	
Type of hob			Built-In Hob	
Number of electric cooking zones			5	
Number of electric cooking areas			Hide	
Heating technology (induction cooking zones and cooking areas, radiant cooking zones, solid plates) per electric cooking zone and/or area			Induction	
For circular cooking zones or area: diameter of useful surface area per electric heated cooking zone, rounded to the nearest 5 mm	Middle Front	Ø	21,0	cm
For non-circular cooking zones or areas: length and width of useful surface area per electric heated cooking zone or area, rounded to the nearest 5 mm	Left Front	L x W	22.3 x 22,0	cm
	Left Rear	L x W	22.3 x 22,0	cm
	Right Front	L x W	22.3 x 22,0	cm
	Right Rear	L x W	22.3 x 22,0	cm
Energy consumption per cooking zone or area calculated per kg	Left	EC <sup>electric cooking</sup>	179.6	Wh/kg
	Left	EC <sup>electric cooking</sup>	189.1	Wh/kg
	Middle Front	EC <sup>electric cooking</sup>	189.1	Wh/kg
	Right	EC <sup>electric cooking</sup>	187.3	Wh/kg
	Right	EC <sup>electric cooking</sup>	189.1	Wh/kg
Energy consumption for the hob calculated per kg		EC <sup>electric hob</sup>	186.8	Wh/kg

### EN 60350-2 - Household electric cooking appliances -- Part 2: Hobs - Methods for measuring performance"

#### Suggestions for a correct use in order to reduce the environmental impact:

- When you heat up water, use only the amount you need.
- If it is possible, always put the lids on the cookware.
- Before you activate the cooking zone put the cookware on it.
- Put the smaller cookware on the smaller cooking zones.
- Put the cookware directly in the centre of the cooking zone.
- Use the residual heat to keep the food warm or to melt it."